

Instruction Manual

CAUTIONS

- Read the entire manual carefully before installation and operation.
- It is recommended that the installation be performed by a licensed and qualified electrician.
- Switch off the power source before installation or replacement.
- Before lamp replacement, turn off and allow the lamp to cool down. Heat-resistant gloves are mandatory when handling the lamp.
- Do not touch the LED chip, which may result in lamp damage or malfunction.
- The MEGAMAN[®] LED lamp with Dim to Warm feature works with most conventional dimmers for incandescent lamps or halogens. Please visit <u>www.megaman.cc/user-guide</u> for compatible dimmer lists. Due to possible variations in country dimmer module specifications, please contact your local distributor for a list of compatible dimmers before installation.
- The dimmable LED lamp should be operated within its optimal dimming range:
- Optimal maximum brightness level: 100% brightness
- Optimal minimum brightness level: 10% brightness

(Note: The dimming performance of the optimal minimum brightness (10% brightness) depends on the performance of the dimmer.)

 Certain dimmer switches may cause the dimmable LED lamp to flicker when it is illuminated below the "optimal minimum brightness level". The knob on the dimmer switch can be adjusted to prevent flickering.

- (Note: Certain dimmer switches are equipped with a potentiometer. The potentiometer is a small device to fine-tune the resistance of the dimmer switch to obtain the desired minimum light output of the lamp without flickering. Please refer to steps 4 to 7 of "INSTALLATION" for details.)
- The colour temperature changes from 2800K to 1800K for reflectors and 2700K to 1800K for non-directional lamps when dimmed from 100% to 10%.
- A LED lamp might still operate even when the glass envelop is broken. However, the live parts of the lamp could be exposed, creating a risk of electric shock. If damaged, please switch off the lamp and refrain from using it until it has been replaced correctly.
- For lamps with a weight significantly higher than that of the lamps for which they are a replacement, attention should be drawn to the fact that the increased weight may reduce the mechanical stability of certain luminaires and lampholders and may impair contact making and lamp retention.
- The manufacturer accepts no liability for any damage resulting from the misuse of the lamp or from when it is used with inappropriate equipment.
- Consult the local distributor if there are any questions about this product.

LOADING RANGE

- · Please pay attention to the Minimum and Maximum Loads of the dimmer switch used.
- For the best dimming performance, the number of LED lamp(s) connected should be within the minimum and maximum loads of the dimmer switch used. Please see the following for the calculation:

MINIMUM Load Requirement

Calculation:

Minimum load of dimmer switch x 1/6 = Minimum wattage of lamp(s) required

For instance, if the minimum load of a dimmer switch is 60W, the minimum wattage for the total LED lamp(s) connected should be at least 10W ($60W \times 1/6$) or above.

The minimum load of the dimmer switch	Minimum wattage of the total LED lamp(s) required	Minimum number of the LED lamp(s) required
60W	60W x 1/6 = 10W	10W / 8W = 1.25 pieces (i.e 2 pieces)

The dimmable LED lamp may flicker if the total wattage of the LED lamp(s) connected is below the minimum load of the dimmer switch.

MAXIMUM Load Requirement

Calculation:

Maximum load of dimmer switch x 1/5 = Maximum wattage of lamp(s) allowed

For instance, if the maximum load of a dimmer switch is 300W, the maximum wattage for the total LED lamp(s) connected should be 60W (300W x 1/5) or below.

The maximum load of the dimmer switch	Maximum wattage of the total LED lamp(s) allowed	Maximum number of the LED lamp(s) allowed
300W	300W x 1/5 = 60W	60W / 8W = 7.5 pieces (i.e 7 pieces)

Malfunction or failure of the dimmer switch may occur if the total wattage of the LED lamp(s) connected exceeds the maximum load of the dimmer switch.



Installation





After adjustment, place the cover back on the dimmer switch. The installation is complete.



Switch the lamp OFF and remove the cover of the dimmer switch; on some dimmer switches, the potentiometer may be visible.



Slowly adjust the potentiometer with a screwdriver until the lamp illuminates, and then turn the potentiometer in the reverse direction until it reaches the desired minimum brightness level without flickering.



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

